

MAINTENANCE SHEET TROLLEY

POINTS OF ATTENTION DURING USE

- In direct sunlight, the colour of the wood will change.
- Wipe away grease stains on the wood as soon as possible.
- Wood is a natural product and is "alive".

MAINTENANCE OF TROLLEY

FEATURES

- Powder-coated aluminium
- "Tente" wheels with ball bearings

MAINTENANCE

- Clean the base with warm water;
- Use mild soap for stubborn stains;
- Use a soft sponge or cloth, not an abrasive sponge.

WOOD MAINTENANCE

PROPERTIES

- Teak is a hardwood species, grade AB with durability class I.
- The wood has been carefully controlled.
- The wood is a natural product and can start to crack due to drying out.

TREATMENT

The wood of our trolleys is delivered treated. They are treated with Rubio Monocoat. This product enhances the colour of the wood and stops stains and ageing.

MAINTENANCE

- Use green soap to remove grease stains from the wood. Let the soap soak in for 15 minutes and clean with a soft sponge. Then rinse the wood with water.
- Grease stains which are noticed immediately can be cleaned off with a damp cloth and washing-up liquid.
- Do not use aggressive agents to clean the wood.
- After some time, the wood may stain from cooking. To return it to its original state, it can possibly be sanded and treated again with Rubio Monocoat.
- Always cover your trolley with the cover when not in use.

*The induction devices supplied with your trolley are not waterproof

*

COOKING PLATES

POINTS OF ATTENTION DURING USE

- Our induction hobs can stand a temperature of -28°C to +80°C and a humidity of 95%.
- The induction hobs are not 100% waterproof due to ventilation needed to cool the electronics down.
- The induction hobs need to be covered at all times when not in use.
- Be aware that no water can go into the electronics
- It is better to install the induction hobs under a shelter and do not leave them in the rain the entire year. A small rain shower is not a problem.
- The more you use your induction hob, the better, so condensation cannot touch the electronics.
- If you will not use the induction hob for a few weeks, we advise you to store them in a dry place.